

Mechanical and Digital PORTABLE FLOOR SCALES



LEGAL FOR TRADE



MECHANICAL

These "legal-for-trade" portable floor scales let the weighing come to you. The mechanical models offer maintenance-free operation through their lever system. They're built to provide long-term use in tough environments. The die-cast beam with easy-to-read numbers is viewable from the front or back.

DIGITAL

Large 5" diameter heavy-duty rubolene wheels make the scales easy to roll wherever they are needed. Choose from two different digital weight indicators with serial connectivity for economical and reliable digital speed and precision.

Whether you prefer mechanical or digital, these scales are dependable, rugged and durable!

DETECTO PORTABLE FLOOR SCALES

PORTABLE DIGITAL FLOOR SCALES

These "legal-for-trade" digital platform scales provide fast, portable, accurate performances that let the weighing come to where you need it. Enjoy digital speed and precision with your choice of weight indicators to suit your specific needs. Large 5" diameter heavy-duty rubolene wheels make the scales easy to roll wherever they are needed.

MODEL	CAPACITY
5852F-204	500 lb x 0.2 lb / 220 kg x 0.1 kg
8852F-204	1,000 lb x 0.5 lb / 440 kg x 0.2 kg

Platform Size: 19" W x 28" D / 48 cm W x 71 cm D
Wheels: Large 5" (13 cm) dia. heavy-duty rubolene
Power: 6"C" size alkaline batteries (not included). AC adapter included.
Shipping Weight: 108 lb / 49 kg



INDICATOR FEATURES:

- General purpose enclosure
- Battery or AC power
- Large 1"/25 mm high LCD display
- Pushbutton zero
- lb/kg switch
- Bi-directional serial port
- Auto shutoff and sleep modes

MODEL	CAPACITY
5852F-210	500 lb x 0.2 lb / 220 kg x 0.1 kg
8852F-210	1,000 lb x 0.5 lb / 440 kg x 0.2 kg

Platform Size: 19" W x 28" D / 48 cm W x 71 cm D
Wheels: Large 5" (13 cm) dia. heavy-duty rubolene
Power: 115/230 VAC
Shipping Weight: 108 lb / 49 kg



INDICATOR FEATURES:

- NEMA 4X/IP66 stainless steel enclosure
- AC power
- 0.6"/14 mm high high LED display
- Numeric keypad
- Pushbutton and keypad tare
- Bi-directional serial port
- Checkweighing

PORTABLE WEIGH BEAM FLOOR SCALES

Constructed entirely of heavy-duty welded fabricated steel bases and electrostatically coated with long-life paint, the 854F and 954F Series provide portable, fast, accurate performances. These models come in your choice of platforms sizes (19" W x 28" D or 28" W x 28" D), and the simplified lever system offers maintenance-free, simple operation. Large 5" diameter heavy-duty rubolene wheels make the scales easy to roll wherever they are needed. The die-cast beam with easy-to-read numbers can be viewed from the front or back of the scale.

MODEL	CAPACITY	BEAM - FRONT	BEAM - BACK	PLATFORM SIZE
854F100P	1,000 lb	100 lb x 0.5 lb	100 lb x 0.5 lb	19" x 28" / 48 cm x 71 cm
854F50P	500 lb	50 lb x 0.25 lb	50 lb x 0.25 lb	19" x 28" / 48 cm x 71 cm
854F50K	500 kg	50 kg x 0.25 kg	50 kg x 0.25 kg	19" x 28" / 48 cm x 71 cm
854F50PK	500 lb / 200 kg	20 kg x 100 g	50 lb x 0.25 lb	19" x 28" / 48 cm x 71 cm
854F100PK	1,000 lb / 500 kg	50 kg x 0.25 kg	100 lb x .5 lb	19" x 28" / 48 cm x 71 cm
954F100P	2,000 lb	100 lb x 0.5 lb	100 lb x 0.5 lb	28" x 28" / 71 cm x 71 cm
954F50K	1,000 kg	50 kg x 0.25 kg	50 kg x 0.25 kg	28" x 28" / 71 cm x 71 cm

Wheels: Large 5" (13 cm) diameter heavy-duty rubolene
Overall Dimensions 854F: 45" H x 24" W x 35" D" / 11 cm H x 61 cm W x 89 cm D
 954F: 45" H x 33" W x 35" D" / 11 cm H x 84 cm W x 89 cm D
Shipping Weights 854F: 132 lb / 60 kg
 954F: 206 lb / 93 kg



Detecto Scale reserves the right to improve, enhance, or modify features and specifications without prior notice.


 A Division of Cardinal Scale Manufacturing Co.
 203 E. Daugberty, Webb City, MO 64870 USA
 Ph: 417-673-4631 or 1-800-641-2008 Fax: 417-673-5001
 www.Detecto.com

Sold By:

